


6. Exploded View and Parts List

GXE1395/UCX



No	New Code No.	Old Code No.	Description	Specification	Qty	Remarks
1	●AA92-80101A		ASSY-HOLDER,SPK	DP,ABS,VO,WP100016R5W,TIL	1	
2	AA61-40051A	33093-0016-000	HINGE-ASSY,L	ZUDOBF,3374G	1	
3	AA61-40050A	33093-0015-000	HINGE-ASSY,R	ZUDOBF,3374G	1	
4	AA63-50199A	34003-0097-000	GRILLE-WOOFER,L	SECC,T0.5,3374G	1	
5	AA63-50198A	34003-0096-000	GRILLE-WOOFER,R	SECC,T0.5,3374G	1	
17	● AA92-30155A		ASSY-CABINET,FRONT	GXE1395/UCX	1	
	AA64-30917A		CABINET-FRONT	DP,HIPS,VO,BLK,WP1000	1	
18	AA64-40253A	34073-0108-000	WINDOW-REMOCON	ABS,HB,3374G	1	
19	AA64-10364A	34083-0244-000	KNOB-MENU	ABS,HB,BLK,3374G	1	
20	AA61-60003U	36674-142-920	SPRING-CS	SUS304,0.4,CD5.5,H12	1	
21	AA64-10363A	34083-0242-000	KNOB-POWER	ABS,HB,BLK,3374G	1	
22	AA61-60003U	36674-142-920	SPRING-CS	SUS304,0.4,CD5.5,H12	1	
23	AA64-80020A	33003-0013-000	LEG-BOTTOM	HIPS,VO,BLK,3374G	2	
24	6002-000507	37148-530-121	SCREW-TAPPING	RH,2,M4,L12,ZPC(YEL),SW	2	
25	AA61-10362A		BRACKET-STAND	SECC,T1.6,BLK,3374G	1	
26	● AA91-70055A		ASSY-STAND	DP,AA91-70054A,3374G	1	
27	AA60-10002A	37144-001-210	SCREW-TAPPING	RH,M4,L12,ZPC(YEL),CD	3	
28	AA61-40053A	33383-0004-000	STOPPER-PCB	HIPS,HB,WHT,ALL,MODEL	1	
29	● AA97-90003A		ASSY-PCB,F/AV	DP,GXE1395/UCX,KG1	1	
30	6002-000514	37148-540-153	SCREW-TAPPING	RH,2,M4,L15,ZPC(BLK),SW	2	
31	AA59-60002B	A1294-0063	MODULE-REMOCON	ORC---50HF,38KHZ,940MM,ME	1	
32	AA64-10616A		KNOB-CONTROL	DP,AA64-10361A,3374	1	
33	AA64-40257A	34164-0083-000	INDICATOR-LED,S	ABS,HB,3374G	1	
34	●AA97-80003A		ASSY-PCB,CONTROL	KG1,GXE1395,SMX,SEA	1	
	3404-000176	33609-101-003	SWITCH-TACT	12V,50MA,90-150GF,6X6MM,S	7	
35	AA65-30016A	36635-001-910	CLAMP-D,COTL	NYLON,VO,NTR,DADH-360	2	
36	AA60-10017A	37124-100-830	SCREW-ASSY(CRT+CF)	WC,RH,M5,L35,SWRCH18A	4	
37	AA03-10001D	32019-400-083	CRT-COLOR	A34KQV42X,+380MG,14",90	1	
38	AA63-50200A	34003-0119-000	GRILLE-WOOFER,T	SECC,T0.5,PA110	1	
39	AA64-30698A	32001-0249-000	CABINET-TOP	HIPS,VO,BLK,3374G	1	
40	AA42-10001C	34509-223-022	ANT-ROD	DP,4S,500MM,MT,UL	1	
41	6002-000514	37148-540-153	SCREW-TAPPING(TC+CB)	RH,2,M4,L15,ZPC(BLK),SW	2	
42	6002-000514	37148-540-153	SCREW-TAPPING	RH,2,M4,L15,ZPC(BLK),SW	4	
43			COVER			
44	●AA63-30154A		COVER-TOP,ASSY	DP,AA63-30105A	1	
45			SPEAKER-GENERAL			
46	6002-000514	37148-540-153	SCREW-TAPPING	RH,2,M4,L15,ZPC(BLK),SW	4	
47	AA64-30916A		CABINET-BACK	DP,VO,AA64-30701A	1	
48	6002-000514	37148-540-153	SCREW-TAPPING(CB+CF)	RH,2,M4,L15,ZPC(BLK),SW	4	
49	AA39-10002X	A6006-0253	POWER-CORD	KJ-10,SPT2,2.4M,HOUS,UL	1	
50	● AA96-60363A		ASSY-H/S,SOUND(IC601)	TDA7266	1	
51	AA40-10005A		TUNER-F/S	TECC1880PK25B,NTSC/USA	1	
52	3722-000499	A3040-0198	JACK-RCA	9P(S),SN	1	
53	AA59-40002F	37179-0006-000	MODULE-RF,SW	2GR-10UT,NTSC,USA	1	
54	● AA96-60042A	● 3Y82-20068-010	ASSY-H/S,VERT(Q401)	KSD5071YDI	1	
55	AA26-30002TI	A1201-0059	TRANS-FLY BACK	FCX-14B044,14",125V	1	
56	3704-000102	A3047-0021	SOCKET-CRT	10P,22.5P,14.3PI,SN	1	
57	AA65-30002A	33333-0005-010	CLAMP-FBT	NYLON-66,VO,BLK	1	
	AA65-30009A	36633-101-911	CLAMP-FBT	ABS,VO,BLK	1	
58	●AA97-10031D		ASSY-PCB,MAIN	TXE1395/UCX,KG1,USA	1	
59	● AA96-60368A		ASSY-H/S,POWER(IC602)	KA7631 SIP	1	
60	● AA96-60365A		ASSY-H/S,TRID810	FML-G22S 200v	1	
61	● AA96-20364A		ASSY-H/S,POWER(IC601)	STRS6707 OC	1	